

# Sectional Door Servo

## Control System

( AC220V )

C Series

336000169 V1.3

## Contents

Introduction .....	2
Inspection .....	2
General Characteristic .....	2
Specification .....	3
Operating Instructions .....	5
Maintenance .....	5
Size .....	6
System Operation .....	9
Error Table: .....	15
Port Table: .....	16
Advanced electrical installation .....	17

## Introduction

Thank you for choosing Sectional Door Servo Control System.

Please read this manual carefully before you start to use the system. In this manual you will find instructions for how to set the operating code the controller, malfunction diagnostics and debugging, and routine maintenance.

### Notice:

- Before connecting the system to live wire place make sure the power supply is off.
- Please make sure the power voltage in the main circuit is the same as controller's rated voltage. Also please make sure the ground terminal is properly and reliably connect to the ground wire.
- DO NOT touch output terminal directly. DO NOT short circuit the output terminal and out shell.
- After the power supply is cut, and before the LCD is off, there still high voltage electricity in the circuit, so DO NOT touch the internal wiring and electronic components.
- Internal wiring and electronic components are very sensitivity to static electricity, so DO NOT let any object contact the internal wiring and electronic components of motor driver and the main circuit of the touch control panel.

## Inspection

All product has passed inspection and testing before is leaving the factory.

When you open the unit place make sure there is no damage during shipping. Also to confirm the equipment ratings are matching your requirement.

## General Characteristic

Our servo control system is suitable for counterbalanced sectional doors.

The system is in compact package, with high torque and high operating speed, lower noise, high reliability, smooth and soft operating curves.

The system curtain can be controlled by wall switch, push button, bluetooth, radar, safety edge, photo eye, induction loops, etc.

## Specification

## Specification for Controller

Model	DW4	DW4-1	
Enclosure material	ABS		
Dimension(L*W*H)	303x123x145	300x190x144	mm
Installation method	Vertical installation without vibration		
Power supply	1N~200-240		V
Power frequency	50/60		Hz
Rate output power	1.5		KW
External power supply	12		VDC
	0.4		A
Ambient temperature	-20 ~ +50		°C
Storage temperature	-25 ~ +55		°C
Ambient humidity	30%-85%, No condensation		
Place of use	Indoor, no direct sunlight, no dust, corrosive gas, oil mist, water vapor, etc.		
Weight(net)	1.0	1.0	Kg

Specification for Motor

Model	C40	C60	C90	C120	
Rated Output Torque	40	60	90	120	Nm
Rated Output Speed	30				RPM
Motor power	0.45	0.65	1.1	1.5	kW
Power supply	1N ~ AC200-240				V
Power frequency	50/60				Hz
Power current	4	6	10	13	A
Hollow shaft [ $\Phi$ ]	25.4		25.4/31.75		mm
Ambient temperature	-20 ~ +50				°C
Storage temperature	-25 ~ +55				°C
Ambient humidity	30%-85%, No condensation				
IP degree	IP54				
Limit Mode	Absolute Encoder				
Self Locking Mode	Gear self-braking				
Manual Release	Rapid hand chain				
Weight(net) <sup>1)</sup>	11	12	14.5	15	Kg

1)Weight includes hand chain.

## Operating Instructions

### 1. Basic Function

The system can be operated via: 1) control box; 2) jog control; 3) continuous automatic operation; 4) emergency stop; 5) single side operation box; 6) time delay; 7) radar and/or induction loops. Please refer to wiring terminal for external connections.

### 2. Control Key/Button

- a) "↑"Key/Button: Inching control door's opening movement or continuous automatic opening.
- b) "↓"Key/Button: Inching control door's closing movement or continuous automatic closing.
- c) "STOP" Key/Button: control door to stop running.
- d) "Emergency STOP" Key/Button: Push this key under emergency situation it will shutdown the operation and the door will stop and stay at that position
- e) Four key on LCD are main menu key.

### 3. Install limit switch

The limit switch of system uses the built-in absolute encoder solution, which is pre-installed in the motor before leaving the factory and does not need to be reinstalled.

### 4. Safety

- 1) The motor and controller **MUST** ground properly;
- 2) During the installation, commission and operation **NO ONE** is permitted to stand under the door and stand in the operating path;
- 3) While installing and testing the motor package, at least half of the door's axle **MUST** be inserted into the reducer.
- 4) Check if there are any obstacles in the operating path, if there are please remove the obstacles before lowering the gate.
- 5) **DO NOT** disassemble the controller and motor; any damages due to this action are **NOT** covered under free warranty.


The company reserves the right to modify the product, according to improvement of technology and production process, while the basic characteristics of the product may remain the same.

## Maintenance


The mounting screw for the controller and motor must be inspected regularly to prevent screws from getting loose and falling off. Check the internal and external wirings. Check and change the oil for the reducer on a regular basis.

Size



UNIT: mm





DW4 Controller



DW4-1 Controller



**C40/C60 Moter**



**C90/C120 Motor**

## System Operation

MAIN-----

TORQUE: (disply)  
MODE: (mode)  
STATUS: (status)  
Info Err Set Mode

(disply): Torque, Speed, Position.

(mode): Auto, Jog.

(status): OK, Opening, Closing, Fault, Safety, Maintenance etc.

Mode

Press Mode key, input password (6668) .

Password  
6666  
+ - Ok Esc

Change the operation mode (Auto, Jog).

Mode Setting  
AUTO  
Adj Save Esc

Set

Press Set key, input password (default 6668).

Input Password  
6666  
+ - Ok Esc

## 1.Parameter

Index	Parameter	Value	Default
1	Opening Speed	20-120	80
2	Closing Speed	20-120	70
3	Open Slowdown Dist	30-500	50
4	Close Slowdown Dist	30-500	50
5	Auto Closing Time	<ul style="list-style-type: none"> <li>● 0:Disable</li> <li>● 1-240 s</li> </ul>	0
6	Output 1 Config	<ul style="list-style-type: none"> <li>● Non-close Limit ● Close Limit</li> <li>● Non-open Limit ● Open Limit</li> <li>● Opening ● Closing</li> <li>● Non-limit Position</li> <li>● Limit Position</li> <li>● Reach Close Limit</li> <li>● Fault Warning ● Disable</li> <li>● Double Interlock</li> </ul>	Disable
7	Output 2 Config	<ul style="list-style-type: none"> <li>Automatic Opening</li> <li>● Running ● Stopped</li> <li>● E-Stop State</li> <li>● Auto Closing Countdown</li> <li>● Delayed Opening Countdown</li> <li>● Safety Signal</li> <li>● Normal State Output</li> </ul>	Disable
8	Partial Opening	10-100%	100
9	Safe Signal Height	Set the current position of the door to the failure height of safety signal	
10	Display Config	<ul style="list-style-type: none"> <li>● Position</li> <li>● Speed</li> <li>● Torque</li> </ul>	Torque
11	Backlight Setting	<ul style="list-style-type: none"> <li>● 3 minute auto Off</li> <li>● Signal Wake_up</li> <li>● 60 minute power saving</li> <li>● 60 minute auto off</li> <li>● Always On</li> </ul>	Signal Wake_up
12	Auto Anti Frozen	<ul style="list-style-type: none"> <li>● Off</li> <li>● 1-999 min</li> </ul>	Off
13	Wireless Remote	<ul style="list-style-type: none"> <li>● Off</li> <li>● On</li> </ul>	Enable
14	Safety Edge Set	<ul style="list-style-type: none"> <li>● Disable</li> <li>● Open cmd</li> <li>● Stop cmd</li> </ul>	Disable
15	Input Port Set	<ul style="list-style-type: none"> <li>1.General Port Set</li> <li>2.Manual Open Set</li> <li>3.Manual Close Set</li> <li>4.Manual Stop Set</li> <li>5.Safety Sig Set</li> <li>6.E-Stop Set</li> </ul>	<ul style="list-style-type: none"> <li>Pedestrian Door</li> <li>Enable</li> <li>Enable</li> <li>Enable</li> <li>Enable</li> <li>Enable</li> </ul>

-----2.Limit Switch Setting

Choose the open direction.

Press OPEN-key  
Direction  
Correct?

Next, we shall set the Open and Close Limit.

Open Limit

Close Limit

Finally, we will see the result.

Calibrate  
Programmed

or

Calibrate  
Failure

-----3.Advanced Setting

-----1.Communication

Set RS485 slave address and baudrate.

1. Slave Address  
2. Baud Rate

Slave Address  
1

Baud Rate  
4800

Adj Save Esc

2.Contact Type  
Set the contact type.

Index	Parameter	Value	Default
1	E-Stop	N.O / N.C	N.C
2	Safety Signal	N.O / N.C	N.O
3	General Port	N.O / N.C	N.O

1.E-Stop  
2. Safety Signal  
3. General Port

↑ ↓ Ok Esc

Ext E-Stop  
N.O

Adj Save Esc

3.Adv Parameter  
First, input password (7779).

Password  
7777

+ - Ok Esc

Select the parameter index.

Adv Parameter  
Index\_01

+ - Ok Esc

Change the parameter value.

Adv Parameter  
P01: 0001

+ - Save Esc

4. System Config

5. Auto Test

Run the system auto testing.

Auto Test  
(display)  
0

4. Language

Set the system language.

Language  
English

5. Default

Restore factory settings.

Default ?

Info

1. Input Query

Displays the input states.

Index	Port	State
1	Manual Open	0: No Signal 1: Has Signal
2	Manual Close	
3	Manual Stop	
4	Ext E-Stop	
5	General Port	
6	Safety Signal	
7	Remote Open	
8	Remote Close	
9	Remote Stop	
10	Safety Edge	

```
1. Manual Open      0
2. Manual Close     0
3. Manual Stop      0
↑   ↓             Esc
```

-----2.Sum Counter  
Displays the work cycles.

```
Sum Counter
      88
                               Esc
```

-----3.Fault Memory  
Displays the error history.

```
01. HRR23  No
Limit Settings
2015-11-17 10:25
↑   ↓             Esc
```

-----4.System Query  
Displays the value of selected system register.

```
1. Bus Voltage...
      0
↑   ↓             Esc
```

-----5.Version  
Displays the system version.

-----6.RTC Query  
Displays the current date and time of the real time clock.

```
RTC Query
2015-11-17
12:12:12
                               Esc
```



Shows the current error message.

ERR 19	
Absolute Encoder	
Failure	
More	Esc

### Error Table:

Error Code	Content
ERR01	Over current
ERR03	Under Voltage
ERR04	Over Voltage
ERR05	Over Voltage
ERR06	Locked Rotor
ERR07	Out Of Limit Position
ERR08	EEPROM Failure
ERR09	Over Speed
ERR10	Motor Reversion
ERR11	Overload
ERR12	Sample Current Failure
ERR13	Motor Encoder Failure
ERR14	Initial Rotor Angle Failure
ERR15	Communication Failure
ERR19	Absolute Encoder Failure
ERR20	Run Time Exceeded
ERR22	Safety Exceeded During Cycle
ERR23	No Limit Settings
ERR29	Absolute Encoder Reset
ERR31	Motor Encoder Failure 2
ERR32	Motor Encoder Failure 3
ERR33	Absolute Encoder Failure 2
ERR34	Absolute Encoder Reset 2
ERR35	Absolute Encoder Run Reset
ERR36	Limit Distance Too Short
ERR39	Motor Encoder Failure 4
ERR40	Motor Encoder Failure 5
ERR41	Absolute Encoder Position Unstable
ERR42	Motor Dir Err In Limit Setting
ERR44	Limit Distance Too Long
ERR45	Absolute Encoder Dir Failure

ERR47	Limit HALL Value Not Match
ERR48	Abnormal Door Position
ERR49	Limit Abnormal
ERR50	Motor Thermal Protect
ERR51	Drive Thermal Protect

### Port Table:

#### Port Table Of Controller:



Port	Function	Remark
L	L	
N	N	1N~AC220V input
PE	PE	
L1	L1	
N1	N1	1N~AC220V output, connect to motor
PE	PE	
B1	Motor signal output	Connect to motor
B2		
B3		
S1		
1	Manual open input	NO
2	Manual close input	NO
3	Manual stop input	NO
4	COM/GND	
5	Safety input <sup>1)</sup>	NO(Safety edge, photocell, etc), reverse to open limit when closing
6	Pedestrian Door <sup>1)</sup>	NO, Multifunction port
7	COM/GND	
8	DC+12V	Maximum output current 0.4A
9	COM/GND	
10	Emergency stop input <sup>1)</sup>	NC
11	COM/GND	
24	Output 1A	NO, refer to "Output 1 config"
25	Output 1B	
26	Output 2A	NO, refer to "Output 2 config"
27	Output 2B	

1) The NO/NC state of the input port can be modified by setting relevant parameters.


#### Port Table Of Motor:

Port	Function	Remark
L1	L1	
N1	N1	AC220V input, connect to controller
PE	PE	
B1	Motor signal input	Connect to controller
B2		
B3		
S1		
S2	Hand chain safety input	Connect to chain safety sensor
S3		

Advanced electrical installation



## Radio receiver



SET→Parameter→Wireless Remote→Enable

**Learning:**

After powering on, press the button on the receiver. The red LED indicator on the receiver will remain lit. Then, press and hold the up button on the transmitter until the red LED indicator on the receiver flashes three times and then turns off. The Learning is complete when you release the button.

**Cleaning:**

Press and hold the receiver button, the LED indicator light stays on until it flashes twice and then turns off. Release the button after the code clearing is completed.